

# DIGI PLEX

# DIGI PLEX

## User's Quick Reference Guide

### AC LIGHT

ON = AC power  
OFF = Power failure

### STATUS LIGHT

When Green:

ON = Zones closed  
OFF = Zone(s) open  
FLASH = Exit Delay

When Red:

ON = Area(s) armed  
OFF = Area(s) disarmed  
FLASH = Alarm



The LCD screen will guide you with detailed messages.

Use the arrow buttons to scroll the menu or choices.

Press the corresponding one-touch button for 2 seconds to perform an action without entering your Access Code.

DGP2-641/DGP2-641AC

[CLEAR] = Erases current data entry or reverts to the preceding step.  
[ENTER] = Saves current data and exits current menu.

## HOW TO ARM

1. Enter your [ACCESS CODE], and then...

To **Regular Arm**: Press the [ARM] button.  
(Arms entire area when all zones are closed)

To **Force Arm**: Press the [FORCE] button.  
(Arms entire area without waiting for all zones to close)

To **Stay Arm**: Press the [STAY] button.  
(Arms area's perimeter only, which allows you to remain in the protected area)

To **Instant Arm**: Press the [5] button.  
(Stay arms area, but an alarm will occur instantly if zones open, including entry delay zones)

2. If you have access to more than one area, select the desired area, or press the [0] button for all areas.

## HOW TO DISARM

To **Disarm** when entering:

1. Enter your **[ACCESS CODE]**.
2. Select the area(s) if necessary.

To **Disarm** from within the perimeter:

1. Enter your **[ACCESS CODE]**, and then press the **[DISARM]** button.
2. Select the area(s) if necessary.

## PANIC BUTTONS

To send a silent or audible alarm to your Security Company, press and hold one of the button combinations listed in the table below for 2 seconds.

Panic Alarm Type	Button Combinations
Emergency Panic	Press and hold the <b>[1]</b> and <b>[3]</b> buttons
Auxiliary Panic	Press and hold the <b>[4]</b> and <b>[6]</b> buttons
Fire Panic	Press and hold the <b>[7]</b> and <b>[9]</b> buttons

## HOW TO BYPASS ZONES

When a zone is bypassed, it remains unarmed once the corresponding area is armed.

1. Enter your **[ACCESS CODE]**.
2. Press the **[BYP]** button.
3. Use the **[▲]** and **[▼]** buttons to scroll through the zones, and then press **[BYP]** once the desired zone appears on the screen. If necessary, repeat to bypass more zones.
4. Press **[ENTER]** to save and exit.

## ALARM MEMORY DISPLAY

To view the alarms that occurred during the last armed period:

1. Press the **[MEM]** button.  
All the zones that were breached during the last armed period will scroll on the screen.
2. Press **[CLEAR]** to exit.

\*Some features mentioned in this Quick Start need to be activated by your Installer.

\*We recommend that you test your security system on a weekly basis.